




Original		Recharge		Original		Recharge	
	Power		Power		I/II		Dual
	Input TV		TV/R		Sleep		Sleep
	Input		AV		Up		Up
	ARC		Media		Down		Down
	*+		Shift + Right		Right		Right
	-*		Shift + Left		Left		Left
	Text		Text		OK		Ok
	PIP		3D		Vol+		Vol +
	Size		Format		Vol-		Vol -
	Position		Options		Mute		Mute
	Red/PIP PR-		Red		PR+		Ch +
	Green/PIP PR+		Green		PR-		Ch -
	Yellow/Swap		Yellow		Q.View		Smart
	Blue/PIP Input		Blue		1		1
	Exit		Exit		2		2
	List		List		3		3
	Menu		Menu		4		4



















































Original		Rechange		Original		Rechange	
5	5	5	5				
6	6	6	6				
7	7	7	7				
8	8	8	8				
9	9	9	9				
0	0	0	0				
FAV	FAV	PRE-CH	Pre Ch				
TIME	Time	SHIFT + AV	Shift + AV				
REVEAL	Reveal	AD SUBT	Subt				
INDEX	Index	DISPLAY INFO	Info				









































	Original	Recharge	Original	Recharge
	Power			
	Stop			
	Play			
	Pause			
	I<<			
	>>			
	>>I			
	Menu			
	Up			
	Down			
	Right			
	Left			
	OK			
	1			
	2			
	3			





	Original	Recharge	Original	Recharge
	Power			8
	Input			9
	Stop			0
	Play			
	Pause			
	Rec			
	<<			
	>>			
	PR+			
	PR-			
	1			
	2			
	3			
	4			
	5			
	6			
	7	