





































| Original   | Rechange  |
|--|---|
|  On           |  Power           |
|  Source       |  AV              |
|  Up           |  Up              |
|  Down         |  Down            |
|  Right        |  Right           |
|  Left         |  Left            |
|  Vol+         |  Vol +           |
|  Vol-         |  Vol -           |
|  Play         |  Play            |
|  Pause        |  Pause           |
|  Stop        |  Stop           |
|  Record     |  Rec           |
|  Open/Close |  Eject         |
|  >>I        |  >>I           |
|  I<<        |  I<<           |
|  Mute       |  Mute          |
|  Prog       |  Shift + Sleep |

| Original  | Rechange   |
|---|--|
|  Intro/CT      |  Ok         |
|  Clock         |  Smart      |
|  ADD           |  3D         |
|  PTY           |  Options    |
|  Del           |  Exit       |
|  Timer         |  Shift + AV |
|  Repeat/RDS    |  Text       |
|  Sleep         |  Sleep      |
|  Band          |  Red        |
|  FM ST         |  Green      |
|  CD Info      |  Yellow    |
|  Demo/Dimmer |  Media    |
|  EQ          |  Dual     |
|  B.Boost     |  Back     |
|   |  |
|   |  |
|   |  |

