



Original	Recharge
Open/Close	Eject / Surround
Power	Power
VCR	Shift + 4
DVD	Shift + 2
TV / VCR	TV/Radio /
TV / View	Smart / List
2	2
4	4
1 / Tracking -	1
5	5
3 / Tracking +	3
6	6
7	7
8	8
9	9
Clear	Exit / Cancel / Clear
0	0

Original	Recharge
P.Scan	Blue / Prime Video / Random
Menu	Menu / Home
Setup	Setup / OPT /
Up	Up
PR+	CH+ / Page+
PR-	CH- / Page-
Down	Down
Left	Left
Right	Right
Enter	OK
Edit	Fav / Marker / PC
Display	Display / Media
I<<	I<< / Preset-
>>I	>>I / Preset+
Pause	Pause / Step / Freeze
Play	Play / Slow
<<	<< / Tune-





	Original	Rechange	Original	Rechange
	>>	>> / Tune+		
	Stop	Stop / Hold		
	Rec	Rec / Rec Mode		
	Input	AV / Input / RDS		
	Subtitle	Subtitle / EQ		
	< / Slow -	Vol-		
	Slow + / >	Vol+		
	Copy	Guide / EPG / -/--		
	Angle	Info / Angle		
	Rec Speed	Shift + Rec / Rec Mode		
	Zoom	Zoom / Size		
	Repeat	Green / APP / Repeat		
	A-B	Yellow / YouTube / Repeat		
	Search	Red / Netflix / Search		
	Audio	Audio / Lang I/II		
	Title	Sound / Title		
	Timer	Sleep / Timer		





Original	Recharge
Open/Close	Eject / Surround
Power	Power
VCR	Shift + 4
DVD	Shift + 2
TV / VCR	TV/Radio /
TV / View	Smart / List
2	2
4	4
1 / Tracking -	1
5	5
3 / Tracking +	3
6	6
7	7
8	8
9	9
Clear	Exit / Cancel / Clear
0	0

Original	Recharge
P.Scan	Blue / Prime Video / Random
Menu	Menu / Home
Setup	Setup / OPT /
Up	Up
PR+	CH+ / Page+
PR-	CH- / Page-
Down	Down
Left	Left
Right	Right
Enter	OK
Edit	Fav / Marker / PC
Display	Display / Media
I<<	I<< / Preset-
I>>	I>> / Preset+
Pause	Pause / Step / Freeze
Play	Play / Slow
<<	<< / Tune-



