




Original	Rechange	Original	Rechange
 Power	 Power	 Pause	 Pause
 Open/Close	 Eject	 I<<	 I<<
 Function	 Media	 <<	 <<
 Sleep	 Sleep	 >>	 >>
 Title	 Guide	 >>I	 >>I
 Setup	 Options	 Repeat	 Text
 Display	 Info	 Vol +	 Vol +
 Menu	 Menu	 Vol -	 Vol -
 Up / Preset	 Up	 Mute	 Mute
 Down /	 Down	 Sound Effect	 Dual
 Right / Tuning +	 Right	 Clear	 Exit
 Left / Tuning -	 Left	 S-Title	 Subt
 Enter	 Ok	 Prog / Memo	 Shift + Sleep
 Back	 Back	 1	 1
 *1	 Pre Ch	 2	 2
 Stop	 Stop	 3	 3
 Play	 Play	 4	 4





Original		Recharge		Original		Recharge	
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
	0		0				
	Power Tv	+	Shift + Power				
	Input Tv		AV				
	PR/CH + Tv		Ch +				
	PR/CH - Tv		Ch -				
	Vol + Tv	+	Shift + Vol +				
	Vol - Tv	+	Shift + Vol -				
	*2		Format				
	*3		3D				

