





































































Original	Recharge	Original	Recharge
	Power		Power
	Select Drive		List
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Last View		Pre Ch
	Radio/Tv		TV/R
	CH/Page+		Ch +
	CH/Page-		Ch -
	Internet		Smart
	Netflix		Media
	I<< Skip		I<<
	Skip >>I		>>I
	<< Slow/Search		<<
	Slow/Search >>		>>
	Stop		Stop
	Pause/Resume Live		Pause
	Play		Play
	Rec		Rec
	i/Status		Info
	X/Exit		Exit
	Video Menu		D. Menu
	Guide		Guide
	Function Menu		Menu
	Option		Options
	Return		Back
	Up		Up





Original	Recharge
	Down
	Right
	Left
	Ok
	Red
	Green
	Yellow
	Blue
	+ Shift + Rec
	TEXT Text
	SUBT Subt
	SLEEP Sleep
	FORMAT Format
	3D 3D
	DUAL Dual
	AV AV
	Eject

Original	Recharge
	+ Shift + Left
	+ Shift + Right
	+ Shift + Power
	+ Shift + AV
	Vol +
	Vol -
	+ Shift + Ch +
	+ Shift + Ch -

