



Original	Rechange
Power	Power
Open/Close	Eject
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Step	Format
3D	3D
S.Fit	List
Zoom	Shift + Eject
Digest	TV/R

Original	Rechange
<<	<<
>>	>>
I<<	I<<
>>I	>>I
Stop	Stop
Play	Play
Pause	Pause
Top Menu	Shift + Menu
Menu	Menu
Return	Back
Display	Info
Clear	Exit
Mode	AV
Up	Up
Down	Down
Right	Right
Left	Left



