







































Original	Rechange
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 Shift + Guide
 Recall	 Pre Ch
 P.Mode	 Shift + Format
 S.Mode	 Shift + Dual
 Nicam	 Options

Original	Rechange
 Sleep	 Sleep
 Source	 AV
 CH+	 Ch +
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Info	 Info
 Media	 Media
 Freeze	 Smart
 Aspect	 3D
 EPG	 Guide
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Menu	 Menu





Original	Rechange	Original	Rechange
Exit	Exit	Green	Green
Text	Text	Yellow	Yellow
Play	Play	Blue	Blue
Pause	Pause		
Stop/Hold	Stop		
<<	<<		
Size	Format		
>>/Reveal	>>		
I<</Index	I<<		
>>I/Subpage	>>I		
Lang	Dual		
Subtitle	Subt		
Rec	Rec		
R.List	List		
TV/Radio	TV/R		
Timeshift	Back		
Red	Red		

Original	Rechange
Green	Green
Yellow	Yellow
Blue	Blue

