

















Original		Rechange		Original		Rechange	
	Power		Power		Vol-		Vol-
	1		1		OK		OK
	2		2		Down		Down
	3		3		P-		CH- / Page-
	4		4		i		Info / Angle
	5		5		Format / Picture		Picture / Format
	6		6		TXT		Text / Goto
	7		7		Mute		Mute / Dimmer
	8		8		Red/AKT		Red / Netflix / Search
	9		9		Green/Timer		Sleep / Timer
	0/AV		AV / Input / RDS		Green/Timer		Green / APP / Repeat
	0/AV		0		Yellow/[I]		Yellow / YouTube / Repeat
	Up		Up		Blue/[++]		Blue / Prime Video / Random
	P+		CH+ / Page+		-O		<< / Tune-
	Right		Right		O+		>> / Tune+
	Vol+		Vol+		-*		I<< / Preset-
	Left		Left		*+		>>I / Preset+





Original	Recharge	Original	Recharge
PIP	PIP		
IDTV-?	IDTV-?		
P/C-ATS	P/C-ATS		
AUX	AUX		
















































	Original	Recharge	Original	Recharge
	Power			
	P+			
	P-			
	Rec			
	Play			
	Pause			
	Stop			
	<			
	>			
	<<			
	>>			





Original		Rechange		Original		Rechange	
	Power		Power		Vol-		Vol-
	1		1		OK		OK
	2		2		P-		CH- / Page-
	3		3		Down		Down
	4		4		i		Info / Angle
	5		5		Format / Picture		Picture / Format
	6		6		TXT		Text / Goto
	7		7		Mute		Mute / Dimmer
	8		8		Red/AKT		Red / Netflix / Search
	9		9		Green/Timer		Green / APP / Repeat
	0/AV		AV / Input / RDS		Green/Timer		Sleep / Timer
	0/AV		0		Yellow/[I]		Yellow / YouTube / Repeat
	P+		CH+ / Page+		Blue/[++]		Blue / Prime Video / Random
	Up		Up		-O		<< / Tune-
	Right		Right		O+		>> / Tune+
	Vol+		Vol+		-*		I<< / Preset-
	Left		Left		*+		>>I / Preset+





Original		Recharge		Original		Recharge	
	PIP		Setup / OPT /				
	IDTV-?		Smart / List				
	P/C-ATS		Display / Media				
	AUX	+	Shift + 7				

