




Original	Recharge
Power	Power
Tv/Rad	TV/R
Search	Shift + TV/R
Live Zoom	Eject
*	Menu
Source	AV
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Guide	Guide

Original	Recharge
Q.View	D. Menu
FAV/Quick	Pre Ch
Info	Info
Vol+	Vol +
Vol-	Vol -
Mute	Mute
P+	Ch +
P-	Ch -
Netflix	Shift + Media
Home	Smart
Amazon	Media
Text	Text
Back	Back
T.Opt/Magic Link	Options
Exit	Exit
Up	Up
Down	Down





Original		Recharge		Original		Recharge	
	Right		Right				
	Left		Left				
	OK		Ok				
	AD/*		Subt				
	Rec		Rec				
	Stop		Stop				
	<<		<<				
	Play		Play				
	Pause		Pause				
	>>		>>				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				

