







































































	Original	Rechange	Original	Rechange
	 Step	 Power	 Angle	 Red
	 Search	 TV/R	 Audio	 Dual
	 Mute	 Mute	 Menu PBC	 Menu
	 Source	 AV	 Title	 3D
	 1	 1	 Mode	 Exit
	 2	 2	 Setup	 Options
	 3	 3	 Vol+	 Vol +
	 4	 4	 Vol-	 Vol -
	 5	 5	 Repeat	 Text
	 6	 6	 Slow	 Format
	 7	 7	 Program	 Sleep
	 8	 8	 Zoom	 Eject
	 9	 9	 Up	 Up
	 0	 0	 Down	 Down
	 10+	 Guide	 Right	 Right
	 Display	 Info	 Left	 Left
	 Subtitle	 Subt	 Enter	 Ok



