





Original	Recharge
 Power	 Power
 Tv/SAT	 Smart
 Mute	 Mute
 TV/R	 TV/R
 Goto	 Options
 Audio	 Dual
 Aspect	 3D
 Info	 Info
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9

Original	Recharge
 0	 0
 P+	 Ch +
 P-	 Ch -
 Recall	 Back
 DEV	 Media
 Up/CH+	 Up
 Down/CH-	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 Menu	 Menu
 EPG	 Guide
 FAV	 Pre Ch
 Exit	 Exit
 TTX	 Text





Original		Rechange		Original	Rechange
	Red		Red		
	Green		Green		
	Yellow		Yellow		
	Blue/Option		Blue		
	Subt.		Subt		
	Zoom		Eject		
	<<		<<		
	>>		>>		
	Play		Play		
	Pause		Pause		
	Stop		Stop		
	Rec		Rec		
	MP		AV		
	V-Format		Format		
	A1		List		
	B2		Sleep		

