













| Original | Rechange | Original | Rechange |
|---|----------|---|----------------|
|  | Power |  | Power |
|  | Sleep |  | Sleep |
|  | Mute |  | Mute |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | Back |  | Back |
|  | Null |  | Shift + Eject |
|  | Vol+ |  | Vol + |
|  | Vol- |  | Vol - |
|  | Aspect |  | 3D |
|  | Audio |  | Dual |
|  | Display |  | Info |
|  | CH+ |  | Ch + |
|  | CH- |  | Ch - |
|  | Menu |  | Menu |
|  | Exit |  | Exit |
|  | Up |  | Up |
|  | Down |  | Down |
|  | Right |  | Right |
|  | Left |  | Left |
|  | OK/Enter |  | Ok |
|  | Input |  | AV |
|  | PMode |  | Shift + Format |
|  | Ch.List |  | List |
|  | SMode |  | Shift + Dual |
|  | FAV |  | Pre Ch |





| Original | | Recharge | | Original | | Recharge | |
|---|---------------|---|--------------|---|-------------|---|--------|
|  | EPG |  | Guide |  | >> |  | >> |
|  | TV/Radio |  | TV/R |  | << |  | << |
|  | Subtitle |  | Subt |  | Red |  | Red |
|  | Text |  | Text |  | Green |  | Green |
|  | Index |  | Smart |  | Yellow/ (A) |  | Yellow |
|  | Mix |  | Eject |  | Blue |  | Blue |
|  | Hold |  | Media | | | | |
|  | Reveal |  | Options | | | | |
|  | Subpage |  | Shift + Subt | | | | |
|  | Cancel |  | D. Menu | | | | |
|  | Size |  | Format | | | | |
|  | Rec |  | Rec | | | | |
|  | Stop |  | Stop | | | | |
|  | Play |  | Play | | | | |
|  | T-Shift/Pause |  | Pause | | | | |
|  | << |  | << | | | | |
|  | >> |  | >> | | | | |

