

















































| Original  | Rechange  |
|---|---|
|  Eject   |  Eject / Surround    |
|  HDD     |  Shift + 7           |
|  DVD     |  Shift + 2           |
|  Power   |  Power               |
|  1       |  1                   |
|  2       |  2                   |
|  3       |  3                   |
|  Prog+   |  CH+ / Page+         |
|  4       |  4                   |
|  5       |  5                   |
|  6      |  6                  |
|  Prog- |  CH- / Page-       |
|  7     |  7                 |
|  8     |  8                 |
|  9     |  9                 |
|  Input |  AV / Input / RDS  |
|  Audio |  Audio / Lang I/II |

| Original  | Rechange  |
|---|---|
|  0           |  0                         |
|  Clear       |  Exit / Cancel / Clear     |
|  TV/DVD      |  TV/Radio /                |
|  Subtitle    |  Subtitle / EQ             |
|  Angle       |  Info / Angle              |
|  Play Mode   |  Shift + Play /            |
|  Zoom        |  Zoom / Size               |
|  System Menu |  Shift + D.Menu / Top Menu |
|  Title List  |  Sound / Title             |
|  Timer       |  Sleep / Timer             |
|  Top Menu   |  D.Menu / Top             |
|  Up        |  Up                      |
|  Menu      |  Menu / Home             |
|  Left      |  Left                    |
|  Enter     |  OK                      |
|  Right     |  Right                   |
|  Return    |  Back / Return           |



