







































































Original		Recharge		Original		Recharge	
	Power		Power		Green		Green
	Menu		Menu		Yellow		Yellow
	Exit		Exit		Blue		Blue
	Mute		Mute		Q.Menu		D. Menu
	1		1		Back		Back
	2		2		Up		Up
	3		3		Right		Right
	4		4		Down		Down
	5		5		Left		Left
	6		6		OK		Ok
	7		7		EPG		Guide
	8		8		YouTube		Media
	9		9		Vol +		Vol +
	0		0		Vol -		Vol -
	Info		Info		Source		AV
	Audio / I/II		Dual		Text		Text
	Red		Red		P +		Ch +









































































Original		Recharge		Original		Recharge	
	P -		Ch -				
	List		List				
	Netflix		Smart				
	Play		Play				
	Pause		Pause				
	Stop		Stop				
	Rec		Rec				
	<<		<<				
	<<		<<				
	>>		>>				
	>>		>>				





Original		Rechange		Original		Rechange	
	Power		Power		1		1
	Mute		Mute		2		2
	Play		Play		3		3
	Pause / Mix		Pause		4		4
	Pause / Mix		Shift + Text		5		5
	Stop / Hold		Stop		6		6
	Size		Format		7		7
	<< / Timer		<<		8		8
	<< / Timer		Shift + Power		9		9
	I<< / Index		I<<		0		0
	>>I / Reveal		>>I		Settings		Options
	>> / Cancel		>>		Exit		Exit
	>> / Cancel		Shift + Exit		Up		Up
	Info		Info		Left		Left
	Audio / I/II		Dual		OK		Ok
	Text		Text		Right		Right
	Back / Del		Back		Down		Down





Original		Recharge		Original	Recharge
	Netflix		Media		
	Vol +		Vol +		
	Vol -		Vol -		
	YouTube		Shift + Media		
	Home / Source		AV		
	Home / Source		Smart		
	P +		Ch +		
	P -		Ch -		
	Red		Red		
	Green		Green		
	Yellow		Yellow		
	Blue		Blue		
	EPG		Guide		
	List		List		
	Q.Menu		Menu		

