







































































Original		Rechange		Original		Rechange	
	Power		Power		CH List		List
	Source		AV		CH+		Ch +
	1		1		CH-		Ch -
	2		2		Settings		Options
	3		3		Home		Smart
	4		4		Guide		Guide
	5		5		E-Manual		D. Menu
	6		6		Info		Info
	7		7		Return		Back
	8		8		Exit		Exit
	9		9		Up		Up
	0		0		Down		Down
	TTX/MIX		Text		Right		Right
	PRE-CH		Pre Ch		Left		Left
	Vol+		Vol +		Enter		Ok
	Vol-		Vol -		Red		Red
	Mute		Mute		Green		Green



