





































| Original | Recharge | Original | Recharge |
|---|------------------|---|----------|
|  | Power |  | Power |
|  | Vol+ |  | Vol + |
|  | Vol- |  | Vol - |
|  | Mute |  | Mute |
|  | Bass+ |  | Ch + |
|  | Bass- |  | Ch - |
|  | Feedback |  | Options |
|  | AUX |  | AV |
|  | Connect |  | Menu |
|  | Soundshift |  | Dual |
|  | Virtual Surround |  | Smart |
|  | Harman Volume |  | Subt |
|  | Optical |  | Text |
|  | Bluetooth |  | Info |
|  | HDMI TV |  | List |
|  | HDMI 1 |  | Sleep |
|  | HDMI 2 |  | Eject |
| | |  | HDMI 3 |
| | |  | TV/R |

