







































































Original		Recharge		Original		Recharge	
	Power		Power		P+		Ch +
	1		1		P-		Ch -
	2		2		Guide		Guide
	3		3		Menu		Menu
	4		4		i		Info
	5		5		Back		Back
	6		6		Exit		Exit
	7		7		Up		Up
	8		8		Down		Down
	9		9		Right		Right
	0		0		Left		Left
	Lang		Dual		OK		Ok
	TXT		Text		Netflix		Media
	Vol+		Vol +		F Play		TV/R
	Vol-		Vol -		You Tube		Smart
	Mute		Mute		Prime Video		Options
	Source		AV		Red		Red





Original		Recharge		Original		Recharge	
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	<<		<<				
	Pause		Pause				
	>>		>>				
	Rec		Rec				
	Play		Play				
	Stop		Stop				

