




































































































Original	Recharge
 Power	 Power
 Audio I/II	 Dual
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Sleep	 Sleep
 Recall	 Back
 Exit	 Exit
 Menu	 Menu

Original	Recharge
 Source	 AV
 Info	 Info
 Up	 Up
 Right	 Right
 Down	 Down
 Left	 Left
 OK	 Ok
 Vol +	 Vol +
 Vol -	 Vol -
 CH +	 Ch +
 CH -	 Ch -
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 P.Mode	 Format
 S.Mode	 Shift +  Dual





Original	Recharge	Original	Recharge
 P.Size	 Eject		
 Subtitle	 Subt		
 Play/Pause / TS	 Play		
 Play/Pause / TS	 Pause		
 Stop	 Stop		
 Rec	 Rec		
 Text	 Text		
 << / PVR List	 <<		
 << / PVR List	 List		
 >> / DTV/Radio	 >>		
 >> / DTV/Radio	 TV/R		
 I<< / Fav.CH	 I<<		
 I<< / Fav.CH	 Pre Ch		
 >>I / Guide	 >>I		
 >>I / Guide	 Guide		

