







































































Original	Rechange	Original	Rechange
 Power	 Power	 0/Mark	 0
 Hi-Lite	 Smart	 Disc Set	 Menu
 Previous	 Pre Ch	 Track Set	 D. Menu
 Best	 Media	 Time Chara	 Sleep
 Repeat	 Text	 Title Display	 Info
 Mode	 3D	 Title Input	 AV
 PGM	 Options	 Cursor >	 Right
 Clear	 Exit	 < Cursor	 Left
 1	 1	 Disc+	 Ch +
 2	 2	 Disc-	 Ch -
 3	 3	 <<	 <<
 4	 4	 >>	 >>
 5	 5	 I<<	 I<<
 6	 6	 >>I	 >>I
 7	 7	 Stop	 Stop
 8	 8	 Pause	 Pause
 9	 9	 Play	 Play



