







































































Original		Rechange		Original		Rechange	
	Power		Power		7		7
	SAT		AV		8		8
	Mute		Mute		9		9
	PGUP		Shift + Ch +		0		0
	PGDN		Shift + Ch -		SUB		Subt
	FAV +		Shift + Right		Audio		Dual
	FAV -		Shift + Left		TV / R		TV/R
	Red		Red		Sleep		Sleep
	Green		Green		TXT		Text
	Yellow		Yellow		RCL		Back
	Blue		Blue		Menu		Menu
	1		1		Info		Info
	2		2		VL +		Vol +
	3		3		VL -		Vol -
	4		4		Up		Up
	5		5		Right		Right
	6		6		Down		Down





Original	Rechange
	Left
	Ok
	CH +
	CH -
	Guide
	Pre Ch
	<<
	>>
	Pause
	I<<
	>>I
	Rec
	Play / Pause
	Stop
	Media
	Smart
	+ Shift + Media

Original	Rechange
	List
	+ Shift + Stop
	Eject
	Options
	Exit
	+ Shift + Text
	3D
	D. Menu

