



Original	Rechange
 Standby	 Power
 Mute	 Mute
 P/N	 Smart
 Open/Close	 Eject
 <<<	 <<<
 >>>	 >>>
 Play/Pause	 Play
 Stop	 Stop
 I<<<	 I<<<
 >>>I	 >>>I
 Setup	 Options
 Source	 AV
 Info	 Info
 Return/Exit	 Exit
 CH+	 Ch +
 CH-	 Ch -
 Up	 Up

Original	Rechange
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Slow	 Back





Original	Recharge
Goto	Media
Program	Sleep
Title/TTX	Text
Audio	Dual
Subtitle	Subt
Red/Repeat	Red
Green/A-B	Green
Yellow/Menu	Yellow
Blue/Angle	Blue
EPG	Guide
Favorite	Pre Ch
Tv/Radio	TV/R
Zoom	Shift + Eject

Original	Recharge

