






Original		Rechange		Original		Rechange	
	Power		Power				
	AUX		Red				
	TAPE 1/2		Green				
	CD		Yellow				
	TUNER		Blue				
	INC SURR.		Smart				
	DBB		Guide				
	DSC		Pre Ch				
	Vol+		Vol +				
	Vol-		Vol -				
	Mute		Mute				
	>		>>				
	<		<<				
	>>		>>				
	<<		<<				
	Program		Sleep				











Original	Recharge
AUX	A Red
TAPE 1/2	B Green
CD	C Yellow
TUNER	D Blue
INC. SURR.	HOME SMART Smart
1	1
2	2
3	3
DBB	/- GUIDE Guide
DSC	FAV PRE-CH Pre Ch
+ Vol+	+ VOL Vol +
- Vol-	- VOL Vol -
MUTE	MUTE Mute
PAUSE	II Pause
Play	PLAY MODE Play
>	>>

Original	Recharge
<	I<<
Stop	Stop
>>	>>>
<<	<<<
Repeat	REPEAT TEXT Text
Shuffle	APP MEDIA Media
Program	PROG SLEEP Sleep



























Original	Rechange	Original	Rechange
 Power	 Power	 <<	 <<
 AUX	 Red		
 TAPE 1/2	 Green		
 CD	 Yellow		
 Tuner	 Blue		
 INC SURR.	 Smart		
 DBB	 Guide		
 DSC	 Pre Ch		
 Vol+	 Vol +		
 Vol-	 Vol -		
 Mute	 Mute		
 Pause	 Pause		
 Play	 Play		
 >	 >>		
  <	  <<		
 Stop	 Stop		
 >>	 >>		





Original	Rechange	Original	Rechange
 Power	 Power		
 AUX	 Red		
 TAPE 1/2	 Green		
 CD	 Yellow		
 Tuner	 Blue		
 INC. SURR.	 Smart		
 DBB	 Guide		
 DSC	 Pre Ch		
 Vol+	 Vol +		
 Vol-	 Vol -		
 Mute	 Mute		

