





















































Original	Recharge
 Standby / On	 Power
 Input Select	 AV / Input / RDS
 HDMI	 Shift + 0
 Eject	 Eject / Surround
 1	 1
 2	 2
 3	 3
 Prog +	 CH+ / Page+
 4	 4
 5	 5
 6	 6
 Prog -	 CH- / Page-
 7	 7
 8	 8
 9	 9
 Time Shift	 Zoom / Size
 Sat Link	 TV/Radio /

Original	Recharge
 0	 0
 Clear	 Exit / Cancel / Clear
 [i+]	 Info / Angle
 Text	 Text / Goto
 Audio	 Audio / Lang I/II
 Subtitle	 Subtitle / EQ
 Guide	 Guide / EPG / -/-
 Top Menu	 D.Menu / Top
 Up	 Up
 Menu / List	 Menu / Home
 Left	 Left
 Enter / OK	 OK
 Right	 Right
 Display	 Display / Media
 Down	 Down
 Return / Back	 Back / Return
 Red	 Red / Netflix / Search





Original	Recharge
 Green	 Green / APP / Repeat
 Yellow / System	 Yellow / YouTube / Repeat
 Blue / Search	 Shift + Blue / Prime
 Blue / Search	 Blue / Prime Video / Random
 << REV	 << / Tune-
 Play	 Play / Slow
 >> FWD	 >> / Tune+
 I<< Skip	 I<< / Preset-
 Stop	 Stop / Hold
 Skip >>I	 >>I / Preset+
 Pause	 Pause / Step / Freeze
 VCR	 Shift + 4
 DVD	 Shift + 2
 CM Skip	 Sound / Title
 Dubbing	 Picture / Format
 Rec	 Rec / Rec Mode
 Rec Speed	 Shift + Rec / Rec Mode

Original	Recharge
 Setup	 Setup / OPT /
 Timer Set	 Sleep / Timer
 Timer Prog	 Shift + Sleep / Timer
 1.3x / 0.8x Play	 Smart / List

