



Original		Rechange		Original		Rechange	
	Power		Power		Language		Dual
	Mute		Mute		Favourite		Pre Ch
	DVB / Analog		TV/R		Cancel / Exit		Exit
	Multi Media		Media		Menu		Menu
	AV		AV		Aspect		Format
	Normal		Smart		Audio I / II		Shift + Dual
	Vol +		Vol +		Recall		Back
	Vol -		Vol -		S.Effect		Options
	PR/Page +		Ch +		1		1
	PR/Page -		Ch -		2		2
	Up		Up		3		3
	Left		Left		4		4
	OK / Select		Ok		5		5
	Right		Right		6		6
	Down		Down		7		7
	Guide		Guide		8		8
	Subtitle		Subt		9		9





Original		Rechange		Original		Rechange	
	0		0		P.Swap		Shift + Back
	Still		Pause		P.Input		Shift + AV
	Sleep		Sleep		P.PR +		Shift + Ch +
	Red		Red		P.PR -		Shift + Ch -
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Text		Text				
	Reveal		List				
	T.Cancel		Shift + Exit				
	Size		Eject				
	S-Code		Shift + Subt				
	Hold		Stop				
	Mix		Shift + Text				
	Index		Info				
	P.Mode		Shift + Format				
	P.Still / P.Size		Shift + Pause				

