











































































































































| Original  |                        | Recharge  |               | Original  |                   | Recharge  |       |
|---|------------------------|---|---------------|---|-------------------|---|-------|
|    | RCVR On                |    | Power         |    | RCVR Right        |    | Right |
|    | RCVR Standby           |    | Shift + Power |    | RCVR Down         |    | Down  |
|    | RCVR Sleep             |    | Sleep         |    | RCVR Level        |    | Media |
|    | RCVR Return            |    | Back          |    | RCVR Level Up     |    | Smart |
|    | RCVR Setup             |    | Options       |    | RCVR I<<          |    | I<<   |
|    | RCVR                   |    | Ch +          |    | RCVR Play         |    | Play  |
|    | RCVR CH-/Disc-         |    | Ch -          |    | RCVR >>I          |    | >>I   |
|    | RCVR Vol+              |    | Vol +         |    | RCVR <<           |    | <<    |
|    | RCVR Vol-              |    | Vol -         |    | RCVR Stop         |    | Stop  |
|    | RCVR CH Sel / Top Menu |    | Shift + Menu  |    | RCVR >>           |    | >>    |
|   | RCVR CH Sel / Top Menu |   | D. Menu       |   | RCVR Rec /        |   | Rec   |
|  | RCVR Test / Menu       |  | Menu          |  | RCVR Play Rev.    |  | Pause |
|  | RCVR Audio Sel         |  | Dual          |  | Open / Close      |  | Eject |
|  | RCVR Muting            |  | Mute          |  | RCVR Input Sel. 1 |  | 1     |
|  | RCVR Up                |  | Up            |  | RCVR Input Sel. 2 |  | 2     |
|  | RCVR Left              |  | Left          |  | RCVR Input Sel. 3 |  | 3     |
|  | RCVR Enter             |  | Ok            |  | RCVR Input Sel. 4 |  | 4     |





























































| Original  |                        | Rechange  |               | Original  |                   | Rechange  |       |
|---|------------------------|---|---------------|---|-------------------|---|-------|
|    | DVD On                 |    | Power         |    | DVD Play          |    | Play  |
|    | DVD Standby            |    | Shift + Power |    | DVD >>I           |    | >>I   |
|    | DVD Sleep              |    | Sleep         |    | DVD <<            |    | <<    |
|    | DVD Return             |    | Back          |    | DVD Stop          |    | Stop  |
|    | DVD Setup              |    | Options       |    | DVD >>            |    | >>    |
|    | DVD Disc+              |    | Ch +          |    | DVD Random        |    | Rec   |
|    | DVD Disc-              |    | Ch -          |    | DVD Pause         |    | Pause |
|    | DVD Vol+               |    | Vol +         |    | DVD Eject         |    | Exit  |
|    | DVD Vol-               |    | Vol -         |    | DVD Input Sel.    |    | 1     |
|    | DVD CH Sel / Top Menu  |    | Shift + Menu  |    | DVD Input Sel. CD |    | 2     |
|   | DVD CH Sel / Top Menu  |   | D. Menu       |   | DVD Input Sel. V1 |   | 3     |
|  | DVD Test /             |  | Menu          |  | DVD Input Sel. V2 |  | 4     |
|  | DVD Audio Sel / TV/VCR |  | TV/R          |  | DVD Input Sel. V3 |  | 5     |
|  | Muting                 |  | Mute          |  | DVD Input Sel.    |  | 6     |
|  | DVD Angle /            |  | Format        |  | DVD Input Sel. V3 |  | 7     |
|  | DVD Subtitle / Level+  |  | Subt          |  | DVD Input Sel. V4 |  | 8     |
|  | DVD I<<                |  | I<<           |  | DVD Input Sel. V5 |  | 9     |











































































| Original  |          | Rechange  |               | Original  |     | Rechange  |       |
|---|----------|---|---------------|---|-----|---|-------|
|    | On       |    | Power         |  | 2   |  | 2     |
|    | Standby  |    | Shift + Power |  | 3   |  | 3     |
|    | Disc+    |    | Ch +          |  | 4   |  | 4     |
|    | Vol+     |    | Vol +         |  | 5   |  | 5     |
|    | Vol-     |    | Vol -         |  | 6   |  | 6     |
|    | Muting   |    | Mute          |  | 7   |  | 7     |
|    | Subtitle |    | Subt          |  | 8   |  | 8     |
|    | I<<      |    | I<<           |  | 9   |  | 9     |
|    | Play     |    | Play          |  | 0   |  | 0     |
|    | >>I      |    | >>I           |  | +10 |  | Guide |
|   | <<       |   | <<            |   |     |   |       |
|  | Stop     |  | Stop          |   |     |   |       |
|  | >>       |  | >>            |   |     |   |       |
|  | Pause    |  | Pause         |   |     |   |       |
|  | Random   |  | Rec           |   |     |   |       |
|  | Eject    |  | Eject         |   |     |   |       |
|  | 1        |  | 1             |   |     |   |       |





| Original  |             | Rechange  |               | Original  |                   | Rechange  |        |
|---|-------------|---|---------------|---|-------------------|---|--------|
|    | NET A       |    | Smart         |    | Play              |    | Play   |
|    | On          |    | Power         |    | >>                |    | >>     |
|    | Standby     |    | Shift + Power |    | <<                |    | <<     |
|    | Sleep       |    | Sleep         |    | Stop              |    | Stop   |
|    | Display     |    | Info          |    | >>                |    | >>     |
|    | Setup       |    | Options       |    | Rec / Random      |    | Rec    |
|    | CH+ / Disc+ |    | Ch +          |    | Pause / Play Rev. |    | Pause  |
|    | CH- / Disc- |    | Ch -          |    | Eject / Repeat    |    | Exit   |
|    | Vol+        |    | Vol +         |    | Eject / Repeat    |    | Text   |
|    | Vol-        |    | Vol -         |    | Album             |    | Red    |
|   | Up          |   | Up            |   | Artist            |   | Green  |
|  | Left        |  | Left          |  | Genre             |  | Yellow |
|  | Enter       |  | Ok            |  | Playlist          |  | Blue   |
|  | Right       |  | Right         |  | 1 / Symbols       |  | 1      |
|  | Down        |  | Down          |  | 2 / ABC           |  | 2      |
|  | Muting      |  | Mute          |  | 3 / DEF           |  | 3      |
|  | I<<         |  | I<<           |  | 4 / GHI           |  | 4      |



