




















| Original  | Recharge  | Original   | Recharge   |
|---|---|--|--|
|  Power                   |  Power           |  System Menu    |  Menu           |
|  Theatre                 |  Smart           |  1              |  1              |
|  One-Touch Play          |  Shift + Play   |  2              |  2              |
|  Sleep                   |  Sleep           |  3              |  3              |
|  S-Air Mode              |  Red             |  4              |  4              |
|  TV Input                |  AV              |  5              |  5              |
|  Picture Navi            |  Media           |  6              |  6              |
|  Dimmer                  |  Shift + Mute   |  7              |  7              |
|  Display                 |  Info            |  8              |  8              |
|  Function+               |  Ch +            |  9              |  9              |
|  Function-              |  Ch -           |  0             |  0             |
|  Audio                 |  Dual          |  Clear        |  Exit         |
|  Subtitle /            |  Subt          |  Folder-      |  Shift + Ch - |
|  Angle / Memory Select |  Format        |  Folder+      |  Shift + Ch + |
|  Sound Mode            |  Shift + Dual |  DVD Menu     |  D. Menu      |
|  Dynamic Bass          |  Green         |  DVD Top Menu |  Shift + Menu |
|  Night                 |  Yellow        |  Muting       |  Mute         |







































|   | Original               | Recharge  | Original  | Recharge |
|---|------------------------|---|---|----------|
|    | Volume+                |  Vol +           |  | Pause    |
|    | Volume-                |  Vol -           |  | Stop     |
|    | Up                     |                  |   |          |
|    | Left                   |                  |   |          |
|    | OK                     |  Ok              |   |          |
|    | Right                  |                  |   |          |
|    | Down                   |                  |   |          |
|    | Return                 |  Back            |   |          |
|    | Display / Tools        |  Shift + Info    |   |          |
|    | Display / Tools        |  Options         |   |          |
|    | I<< / Preset-          |  I<<             |   |          |
|   | >>I / Preset+          |  >>I            |   |          |
|  | ◀• Replay / <II Step   |  Shift + Left  |   |          |
|  | •➔ Advance / Step II>  |  Shift + Right |   |          |
|  | << / Tuning- / <I Slow |  <<            |   |          |
|  | >> / Tuning+ / Slow I> |  >>            |   |          |
|  | Play                   |  Play          |   |          |





| Original  |          | Rechange  |       | Original  |       | Rechange  |      |
|---|----------|---|-------|---|-------|---|------|
|    | TV Power |    | Power |  | Prog- |  | Ch - |
|    | Menu     |    | Menu  |   |       |   |      |
|    | TV Enter |    | Ok    |   |       |   |      |
|    | 1        |    | 1     |   |       |   |      |
|    | 2        |    | 2     |   |       |   |      |
|    | 3        |    | 3     |   |       |   |      |
|    | 4        |    | 4     |   |       |   |      |
|    | 5        |    | 5     |   |       |   |      |
|    | 6        |    | 6     |   |       |   |      |
|    | 7        |    | 7     |   |       |   |      |
|  | 8        |  | 8     |   |       |   |      |
|  | 9        |  | 9     |   |       |   |      |
|  | 0        |  | 0     |   |       |   |      |
|  | -/--     |  | Guide |   |       |   |      |
|  | Volume+  |  | Vol + |   |       |   |      |
|  | Volume-  |  | Vol - |   |       |   |      |
|  | Prog+    |  | Ch +  |   |       |   |      |

