





























Original	Rechange
 Standby	 Power
 Auto / Eject	 Eject / Surround
 Mute	 Mute / Dimmer
 P.Mode	 Picture / Format
 S.Mode	 Sound / Title
 Info	 Info / Angle
 Nicam	 Audio / Lang I/II
 1	 1
 2	 2
 3	 3
 Menu	 Menu / Home
 4	 4
 5	 5
 6	 6
 Exit / D.Setup	 Setup / OPT /
 Exit / D.Setup	 Exit / Cancel / Clear
 7	 7

Original	Rechange
 8	 8
 9	 9
 Input	 AV / Input / RDS
 0	 0
 Recall	 Back / Return
 Sleep	 Sleep / Timer
 Up	 Up
 Left	 Left
 Enter	 OK
 Right	 Right
 Down	 Down
 CH-	 CH- / Page-
 CH+	 CH+ / Page+
 Vol-	 Vol-
 Vol+	 Vol+
 Text / Slow	 Text / Goto
 Text / Slow	 Shift + Play / Slow





Original		Recharge		Original		Recharge	
	Hold / Play/Pause		Play / Slow		FAV+ / Goto	+	Shift + Up
	Hold / Play/Pause	+	Shift + Stop /		FAV+ / Goto	+	Shift + Text /
	Hold / Play/Pause		Pause / Step / Freeze		Red / D.Prog		TV/Radio /
	Page+ / Stop		Stop / Hold		Red / D.Prog		Red / Netflix / Search
	Page+ / Stop	+	Shift + CH+ /		Green / Step	+	Shift + Pause / Step /
	Page- / Zoom		Zoom / Size		Green / Step		Green / APP / Repeat
	Page- / Zoom	+	Shift + CH- /		Yellow / RPT	+	Shift + Green / APP /
	[≡i] / I<<		I<< / Preset-		Yellow / RPT		Yellow / YouTube / Repeat
	[≡□] / >>I		>>I / Preset+		Blue / A-B	+	Shift + Yellow / YouTube /
	[≡?] / <<		<< / Tune-		Blue / A-B		Blue / Prime Video / Random
	[≡●] / >>		>> / Tune+		List / Angle	+	Shift + Info / Angle
	EPG / D.Menu		D.Menu / Top		List / Angle		Smart / List
	EPG / D.Menu		Guide / EPG / -/-		SUB-T		Subtitle / EQ
	FAV / D.Title	+	Shift + Sound / Title		Aspect	+	Shift + Picture / Format
	FAV / D.Title		Fav / Marker / PC		Rec		Rec / Rec Mode
	FAV- / D.Disp		Display / Media				
	FAV- / D.Disp	+	Shift + Down				

