



















































	Original	Rechange	Original	Rechange
	Power		Power	
	Mute		Mute	
	[i+]/[?]		Info	
	A/B/[+]		TV/R	
	Input/[+]		AV	
	[]		Smart	
	1		1	
	2		2	
	3		3	
	4		4	
	5		5	
	6		6	
	7		7	
	8		8	
	9		9	
	0		0	
	-/--		Guide	



