





















































	Original	Rechange	Original	Rechange
	Power			Text
	Goto			Dual
	Mute			Media
	Source			3D
	1			Stop
	2			Play
	3			Pause
	4			Format
	5			Options
	6			Up
	7			Down
	8			Right
	9			Left
	0			Ok
	10+			Yellow
	Step			Red
	Subtitle			Green





	Original	Rechange	Original	Rechange
	Blue	 D		Blue
	I<<			I<<
	>>I			>>I
	TV/Radio			TV/R
	Repeat/Del			Shift + Text
	Pro/EPG			Guide
	Display			Info
	<</FAV			<<
	>>/Prot			>>

