































































	Original	Recharge	Original	Recharge
	Power			Angle/TTX
	Goto			Audio
	Mute			PBC/Scan
	Source			Title
	1			Stop
	2			Play
	3			Pause
	4			Mode
	5			Setup
	6			Up
	7			Down
	8			Right
	9			Left
	0			Enter
	10+			Yellow/Zoom
	Step			Red/Menu
	Subtitle			Green
				Text
				Dual
				Media
				3D
				Play
				Format
				Options
				Up
				Down
				Right
				Left
				Ok
				Yellow
				Red
				Green



