









































| Original | | Rechange | | Original | | Rechange | |
|---|---------|---|-------|---|----------|---|--------|
|  | Standby |  | Power |  | Rec List |  | List |
|  | DTV/VCR |  | AV |  | Favorite |  | Pre Ch |
|  | Mute |  | Mute |  | Game |  | Smart |
|  | Info |  | Info |  | Recall |  | Back |
|  | Play |  | Play |  | 1 |  | 1 |
|  | Pause |  | Pause |  | 2 |  | 2 |
|  | Menu |  | Menu |  | 3 |  | 3 |
|  | Exit |  | Exit |  | 4 |  | 4 |
|  | CH+ |  | Ch + |  | 5 |  | 5 |
|  | CH- |  | Ch - |  | 6 |  | 6 |
|  | Up |  | Up |  | 7 |  | 7 |
|  | Down |  | Down |  | 8 |  | 8 |
|  | Right |  | Right |  | 9 |  | 9 |
|  | Left |  | Left |  | 0 |  | 0 |
|  | OK |  | Ok |  | Tv/Radio |  | TV/R |
|  | Vol+ |  | Vol + |  | Audio |  | Dual |
|  | Vol- |  | Vol - |  | Subtitle |  | Subt |



