



Original	Recharge
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
List	Smart / List
0/Quick Access	0
Vol+	Vol+
Mute	Mute / Dimmer
CH+	CH+ / Page+
Vol-	Vol-
CH-	CH- / Page-

Original	Recharge
Home	Menu / Home
*	Setup / OPT /
Up	Up
Left	Left
Wheel Up	Shift + Up
Right	Right
OK	OK
Wheel Down	Shift + Down
Down	Down
Back	Back / Return
Guide	Guide / EPG / -/-
Netflix	Shift + Red / Netflix /
Source	AV / Input / RDS
Prime Video	Shift + Blue / Prime
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat



