



































| Original | | Rechange | | Original | | Rechange | |
|---|-----------------|---|-------|---|-----------------|---|-----------------|
|  | Power |  | Power |  | Back |  | Back |
|  | 1 |  | 1 |  | Text |  | Text |
|  | 2 |  | 2 |  | Menu |  | Menu |
|  | 3 |  | 3 |  | Guide |  | Guide |
|  | 4 |  | 4 |  | P+ |  | Ch + |
|  | 5 |  | 5 |  | P- |  | Ch - |
|  | 6 |  | 6 |  | ↑ |  | Shift + Ch + |
|  | 7 |  | 7 |  | ↓ |  | Shift + Ch - |
|  | 8 |  | 8 |  | Up |  | Up |
|  | 9 |  | 9 |  | Left |  | Left |
|  | 0 / □ |  | 0 |  | OK |  | Ok |
|  | Exit / TV/Radio |  | Exit |  | Right |  | Right |
|  | Exit / TV/Radio |  | TV/R |  | Down |  | Down |
|  | Mute |  | Mute |  | Red |  | Red |
|  | Vol- |  | Vol - |  | Green / Option |  | Green |
|  | Vol+ |  | Vol + |  | Green / Option |  | Options |
|  | i |  | Info |  | Yellow / Freeze |  | Yellow |



