

















Original		Rechange		Original		Rechange	
	Power		Power		Up		Up
	Source		AV		Left		Left
	Rec		Rec		OK		Ok
	APP		Media		Right		Right
	<<		<<		Down		Down
	Play / Pause		Play		EPG		Guide
	Play / Pause		Pause		Back		Back
	>>		>>		Vol+		Vol +
	I<<		I<<		Vol-		Vol -
	Stop		Stop		Info		Info
	>>I		>>I		Mute		Mute
	Red		Red		Prog+		Ch +
	Green		Green		Prog-		Ch -
	Yellow		Yellow		1		1
	Blue		Blue		2		2
	Menu		Menu		3		3
	Exit		Exit		4		4



















































Original		Rechange		Original		Rechange	
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
	0		0				
	Audio		Dual				
	Sub		Subt				
	List		List				
	Text		Text				
	Rec List		Smart				





Original		Rechange		Original		Rechange	
	Power		Power		6		6
	APP		Media		7		7
	Menu		Menu		8		8
	Exit		Exit		9		9
	OK		Ok		0		0
	Back		Back		Text		Text
	Vol+		Vol +				
	Vol-		Vol -				
	Info		Info				
	Mute		Mute				
	Prog+		Ch +				
	Prog-		Ch -				
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				

