



| Original | | Rechange | | Original | | Rechange | |
|---|-----------|---|-------|---|-------|---|-------|
|  | Power |  | Power |  | Info |  | Info |
|  | Mute |  | Mute |  | Menu |  | Menu |
|  | 1 |  | 1 |  | Exit |  | Exit |
|  | 2 |  | 2 |  | Text |  | Text |
|  | 3 |  | 3 |  | EPG |  | Guide |
|  | 4 |  | 4 |  | Up |  | Up |
|  | 5 |  | 5 |  | Down |  | Down |
|  | 6 |  | 6 |  | Right |  | Right |
|  | 7 |  | 7 |  | Left |  | Left |
|  | 8 |  | 8 |  | OK |  | Ok |
|  | 9 |  | 9 |  | Stop |  | Stop |
|  | 0 |  | 0 |  | Play |  | Play |
|  | Timeshift |  | Media |  | Pause |  | Pause |
|  | Recall |  | Back |  | << |  | << |
|  | Mark |  | Smart |  | >> |  | >> |
|  | Tv/Radio |  | TV/R |  | Rec |  | Rec |
|  | Source |  | AV |  | I<< |  | I<< |



