
































































Original	Recharge	Original	Recharge
 Power	 Power	 Left / Vol-	 Left
 Mute	 Mute	 Left / Vol-	 Vol -
 Back	 Back	 OK	 Ok
 EPG	 Guide	 FAV	 Pre Ch
 Lang	 Dual	 TV/R	 TV/R
 Info	 Info	 List	 List
 Repeat	 Shift + Text	 Goto	 Media
 TTX	 Text	 1	 1
 S-T	 Subt	 2	 2
 Menu	 Menu	 3	 3
 Exit	 Exit	 4	 4
 Up / CH+	 Up	 5	 5
 Up / CH+	 Ch +	 6	 6
 Down / CH-	 Down	 7	 7
 Down / CH-	 Ch -	 8	 8
 Right / Vol+	 Right	 9	 9
 Right / Vol+	 Vol +	 0	 0



