


Original	Rechange	Original	Rechange
 Power	 Power	 Channel-	 Ch -
 Mute	 Mute	 Up	 Up
 1	 1	 Left	 Left
 2	 2	 OK / List	 Ok
 3	 3	 Right	 Right
 4	 4	 Down	 Down
 5	 5	 Menu	 Menu
 6	 6	 Guide	 Guide
 7	 7	 Record List	 List
 8	 8	 Exit	 Exit
 9	 9	 Red / F1	 Red
 0	 0	 Green / F2	 Green
 Recall	 Back	 Yellow / F3	 Yellow
 i	 Info	 Blue / F4	 Blue
 Volume+	 Vol +	 Option	 Options
 Volume-	 Vol -	 Subtitle	 Subt
 Channel+	 Ch +	 Text	 Text





Original		Recharge		Original		Recharge	
	Audio		Dual				
	VF		Format				
	AR		3D				
	⏻		Sleep				
	TV / Radio		TV/R				
	Rec		Rec				
	Stop		Stop				
	SAT		Media				
	M		Smart				
	<<		<<				
	Pause		Pause				
	Play		Play				
	>>		>>				
	I<		I<<				
	>I		>>I				
	I>		Shift + Play				
	>I<		Shift + Stop				

