



| Original        | Recharge      | Original     | Recharge |
|-----------------|---------------|--------------|----------|
| On              | Power         | Left         | Left     |
| Off             | Shift + Power | 1            | 1        |
| Tone            | List          | 2            | 2        |
| Vol+            | Vol +         | 3            | 3        |
| Vol-            | Vol -         | 4            | 4        |
| Mute            | Mute          | 5            | 5        |
| Test            | Smart         | 6            | 6        |
| Night           | Exit          | 7            | 7        |
| DIM / [≡]       | Text          | 8            | 8        |
| Sleep           | Sleep         | 9            | 9        |
| SPKR/Menu       | Menu          | 0            | 0        |
| Delay/Prev. CH. | Info          | Mem/[≡♦]     | Pre Ch   |
| CH./[≡?]        | TV/R          | Tun-M/[≡+]   | Guide    |
| Digital/[≡X]    | Media         | Tuning ▲     | Ch +     |
| Up              | Up            | Tuning ▼     | Ch -     |
| Down            | Down          | Direct/Green | Green    |
| Right           | Right         | Clear/Yellow | Yellow   |





| Original | Recharge       |
|----------|----------------|
| Preset ▲ | Shift + Ch +   |
| Preset ▼ | Shift + Ch -   |
| OSD      | Back           |
| RDS      | Options        |
| OK       | Ok             |
| Red      | Red            |
| Blue     | Blue           |
| AVR      | Shift + 1      |
| DVD      | Shift + 2      |
| CD       | Shift + 3      |
| Tape     | Shift + 4      |
| VID1     | Shift + 5      |
| VID2     | Shift + 6      |
| AUX      | Shift + 7      |
| HDMI1    | Shift + Red    |
| HDMI2    | Shift + Green  |
| HDMI3    | Shift + Yellow |

| Original              | Recharge  |
|-----------------------|-----------|
| AM/FM                 | Shift + 9 |
| > DVD icon"/> > DVD   | Play      |
| << DVD icon"/> << DVD | <<        |
| >> DVD icon"/> >> DVD | >>        |
| Stop DVD              | Stop      |
| Pause DVD             | Pause     |
| I<</Skip Down         | I<<       |
| Skip Up/>>I           | >>I       |

