







































































	Original	Rechange	Original	Rechange
	ST-BY	 Power	 Next / -/--	 Guide
	Mute	 Mute	 Up / PR+	 Up
	1	 1	 Up / PR+	 Ch +
	2	 2	 Down / PR-	 Down
	3	 3	 Down / PR-	 Ch -
	4	 4	 Right / Vol+	 Right
	5	 5	 Right / Vol+	 Vol +
	6	 6	 Left / Vol-	 Left
	7	 7	 Left / Vol-	 Vol -
	8	 8	 OK	 Ok
	9	 9	 Red	 Red
	0	 0	 Green	 Green
	TV	 Smart	 Yellow	 Yellow
	AV	 AV	 Blue	 Blue
	Menu	 Menu	 PP	 Back
	Text	 Text	 Dual	 Dual
	Before / P/C	 Pre Ch	 SVC	 List





Original		Rechange		Original		Rechange	
	Spatial		Format				
	Size		Eject				
	Hold		Stop				
	Update		Media				
	Index		Info				
	Time		Sleep				
	Reveal		Options				
	Mix		D. Menu				
	TXT / M		TV/R				

