






























































Original	Rechange	Original	Rechange
 Power	 Power	 Pause	 Pause
 CH/Page+	 Ch +	 Stop	 Stop
 CH/Page-	 Ch -	 Home	 Smart
 Sleep	 Sleep	 >>I/Tune+	 >>I
 Mute	 Mute	 I<</Tune-	 I<<
 Volume+	 Vol +	 >>	 >>
 Volume-	 Vol -	 <<	 <<
 Info	 Info	 Green/Movie	 Green
 Option	 Options	 Red/Music	 Red
 Setup	 Menu	 Blue/Game	 Blue
 Back	 Back	 Yellow/Pure	 Yellow
 Up	 Up	 1	 1
 Enter	 Ok	 2	 2
 Down	 Down	 3	 3
 Right	 Right	 4	 4
 Left	 Left	 5	 5
 Play	 Play	 6	 6





Original	Rechange	Original	Rechange
 Power	 Power	 >>	 >>
 CH/Page+	 Ch +	 <<	 <<
 CH/Page-	 Ch -	 >> /Tune+	 >>
 Sleep	 Sleep	 <</Tune-	 <<
 Mute	 Mute	 1	 1
 Volume+	 Vol +	 2	 2
 Volume-	 Vol -	 3	 3
 Back	 Back	 4	 4
 Up	 Up	 5	 5
 Down	 Down	 6	 6
 Right	 Right	 7	 7
 Left	 Left	 8	 8
 Enter	 Ok	 9	 9
 Home	 Smart	 0	 0
 Stop	 Stop	 Smart Select 1	 Text
 Pause	 Pause	 Smart Select 2	 AV
 Play	 Play	 Smart Select 3	 Format


















































Original	Recharge
Smart Select 4	3D
TV Audio	TV/R
Media Player	Shift + Guide
Internet Radio	Pre Ch
CBL/SAT	Shift + 1
DVD	Shift + 2
Blu-ray	Shift + 3
AUX1	Shift + 4
Tuner	Shift + 5
Bluetooth	Shift + 6
Game	Shift + 7
AUX2	Shift + 8
Phono	Shift + 9
USB	Guide
CD	Shift + 0
Online Music	Shift + Pre Ch

Original	Recharge





	Original	Rechange		Original	Rechange
	Power		Power		>> /Tune+
	CH/Page+		Ch +		<</Tune-
	CH/Page-		Ch -		<<
	Sleep		Sleep		>>
	Mute		Mute		1
	Volume+		Vol +		2
	Volume-		Vol -		3
	Back		Back		4
	Up		Up		5
	Down		Down		6
	Right		Right		7
	Left		Left		8
	Enter		Ok		9
	Home		Smart		0
	Stop		Stop		Smart Select 1
	Pause		Pause		Smart Select 2
	Play		Play		Smart Select 3
					Text
					AV
					Format



