



Original	Recharge
Power	Power
Tv/Rad	TV/R
Subtitle	Subt
AD/PIP/*	Dual
TV/PC	Smart
Input	AV
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
List	List

Original	Recharge
Q.View	D. Menu
Vol+	Vol +
Vol-	Vol -
Mute	Mute
Guide	Guide
FAV	Pre Ch
P+	Ch +
P-	Ch -
Text	Text
Info	Info
T.Opt	Options
Settings	Shift + Options
Q.Menu	Menu
Back	Back
Exit	Exit
Up	Up
Down	Down





Original	Recharge
Right	Right
Left	Left
OK	Ok
Simplink	Format
Rec/*	Rec
Stop	Stop
<<<	<<<
Play	Play
Pause	Pause
>>>	>>>
Red	Red
Green	Green
Yellow/Brightness	Yellow
Blue/Brightness+	Blue

Original	Recharge

