















































Original		Rechange		Original		Rechange	
	Open/Close		Eject		6		6
	Play		Play		7		7
	Stop		Stop		8		8
	Pause		Pause		9		9
	Repeat		Text		10		0
	Random Play		TV/R		+10		Guide
	Manual >>		>>		≥20		Pre Ch
	<< Manual		<<		Clear		Exit
	I<<< Track		I<<<		Check		Smart
	Track >>>I		>>>I		PGM		Sleep
	< Index		Left		Time		AV
	Index >		Right				
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				

