







































































Original	Recharge	Original	Recharge
	Power		Power
	Mute		Mute
	Play		Play
	Pause		Pause
	Stop		Stop
	Rec		Rec
	<<		<<
	1<<		1<<
	>>1		>>1
	>>		>>
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Recall		Back
	EPG		Guide
	Menu		Menu
	Sources		AV
	Info		Info
	Smart		Smart
	Exit		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Vol+		Vol +
	Vol-		Vol -





Original	Recharge
 Home	 Shift + Smart
 P+	 Ch +
 P-	 Ch -
 Netflix	 Media
 YouTube	 Shift + Media
 Red	 Red
 Yellow	 Yellow
 Green	 Green
 Blue	 Blue
 V.O.	 Dual
 [≡]	 Text
 Subt.	 Subt

Original	Recharge

