



Original	Rechange
Power	Power
EQ	Subtitle / EQ
LG EQ	Audio / Lang I/II
Open/Close	Eject / Surround
Preset/Folder+	CH+ / Page+
Function	Smart / List
Vol+	Vol+
Preset/Folder-	CH- / Page-
Mute	Mute / Dimmer
Vol-	Vol-
Sleep	Sleep / Timer
Repeat	Green / APP / Repeat
Repeat	Up
Info	Info / Angle
<< / I<< / Tun-	<< / Tune-
<< / I<< / Tun-	I<< / Preset-
<< / I<< / Tun-	Left

Original	Rechange
Stop	Stop / Hold
Stop	OK
>> / >>I /	>> / Tune+
>> / >>I /	>>I / Preset+
>> / >>I /	Right
Program/Memo	TV/Radio /
Play/Pause	Play / Slow
Play/Pause	Pause / Step / Freeze
Play/Pause	Down
Rec	Rec / Rec Mode
Clock	Shift + Sleep / Timer
Time	Menu / Home
Set/RDS	D.Menu / Top
PTY	Setup / OPT /

