

















































Original	Rechange	Original	Rechange
 Power	 Power		 Guide
 Source	 AV	 Swap	 Pre Ch
 Mute	 Mute	 Red	 Red
 Auto	 Smart	 Green	 Green
 Display	 Info	 Yellow	 Yellow
 Sleep	 Sleep	 Blue	 Blue
 TV	 Media	 Up	 Up
 1	 1	 Left	 Left
 2	 2	 Menu	 Menu
 3	 3	 Menu	 Ok
 4	 4	 Right	 Right
 5	 5	 Down	 Down
 6	 6	 P+	 Ch +
 7	 7	 P-	 Ch -
 8	 8	 V+	 Vol +
 9	 9	 V-	 Vol -
 0	 0		

