







































































| Original | Rechange | Original | Rechange |
|--|---|---|---|
|  Power |  Power |  Stop |  Stop |
|  FL Display |  Smart |  Pause |  Pause |
|  TUNER BAND |  Green |  Play |  Play |
|  AUX |  Red |  Disc Skip |  Sleep |
|  Top Menu |  D. Menu |  SFC |  Eject |
|  Menu |  Menu |  CH- |  Ch - |
|  Up |  Up |  CH+ |  Ch + |
|  Left |  Left |  Vol+ |  Vol + |
|  Enter |  Ok |  Vol- |  Vol - |
|  Right |  Right |  Muting |  Mute |
|  Down |  Down |  Subwoofer |  Shift + 4 |
|  Display |  Info |  Action |  Options |
|  Return |  Back |  Subtitle |  Subt |
|  I<< |  I<< |  Audio |  Dual |
|  >>I |  >>I |  Angle |  Format |
|  << |  << |  Marker |  3D |
|  >> |  >> |  CH Select |  Shift + Media |





| Original | Rechange |
|----------------|---------------------|
| TEST | SHIFT + 6 Shift + 6 |
| MIX 2ch | SHIFT + 2 Shift + 2 |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| 0 | 0 |
| >10 / Enter | GUIDE Guide |
| Disc | FAV PRE-CH Pre Ch |
| Seat Position | SHIFT + 1 Shift + 1 |
| Center Focus | SEARCH TV/R TV/R |
| Super Surround | SHIFT + 3 Shift + 3 |

| Original | Rechange |
|--------------|----------------------------------|
| PRO LOGIC | SHIFT + 5 Shift + 5 |
| Disc Manager | DISC NAV LIST List |
| Play Mode | SHIFT + PLAY MODE Shift + Play |
| Cancel | CLEAR EXIT Exit |
| Repeat | REPEAT TEXT Text |
| A-B Repeat | SHIFT + REPEAT TEXT Shift + Text |
| Cinema | APP MEDIA Media |
| Timer | TIMER AV AV |








































| Original | Recharge | Original | Recharge |
|------------|----------|----------|----------|
| Power | Power | | |
| TV Vol- | Vol - | | |
| TV Vol+ | Vol + | | |
| TV / Video | AV | | |
| CH+ | Ch + | | |
| CH- | Ch - | | |
| 1 | 1 | | |
| 2 | 2 | | |
| 3 | 3 | | |
| 4 | 4 | | |
| 5 | 5 | | |
| 6 | 6 | | |
| 7 | 7 | | |
| 8 | 8 | | |
| 9 | 9 | | |
| 0 | 0 | | |
| ≥10 | Guide | | |





| | Original | Recharge | | Original | Recharge |
|---|----------|---|-------|---|----------|
|  | Power |  | Power |  | Play |
|  | 1 |  | 1 | | |
|  | 2 |  | 2 | | |
|  | 3 |  | 3 | | |
|  | 4 |  | 4 | | |
|  | 5 |  | 5 | | |
|  | 6 |  | 6 | | |
|  | 7 |  | 7 | | |
|  | 8 |  | 8 | | |
|  | 9 |  | 9 | | |
|  | 0 |  | 0 | | |
|  | ≥10 |  | Guide | | |
|  | CH+ |  | Ch + | | |
|  | CH- |  | Ch - | | |
|  | Stop |  | Stop | | |
|  | << |  | << | | |
|  | >> |  | >> | | |

