



Original	Rechange	Original	Rechange
MUTE	Mute	MUTE	Mute
POWER	Power	POWER	Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
-/--	-/--	-/--	Guide
AV	AV	AV	AV
MENU	Menu	MENU	Menu
OK	Red	A	Red
OK	OK	OK	Ok

Original	Rechange	Original	Rechange
P.P	Green	B	Green
P.P	P:P	PRE-CH	Pre Ch
ANALOG	Yellow	C	Yellow
ANALOG	Analog	HOME SMART	Smart
Blue	Blue	D	Blue
P+	Up		Up
P+	P+		Ch +
P-	P-		Ch -
P-	Down		Down
VOL+	Right		Right
VOL+	Vol+		Vol +
VOL-	Vol-		Vol -
VOL-	Left		Left
RECALL	Recall	RETURN BACK	Back
SLEEP	Sleep	PROG SLEEP	Sleep
STATUS	Status	ECO 3D	3D
TV/TXT	Tv/TXT	REPEAT TEXT	Text





Original		Recharge		Original		Recharge	
	Stop		Stop				
	Reveal		Media				
	Size		Format				
	Mix		Options				
	Index		Info				
	Subcode		Subt				
	Cancel		Shift + Back				

