













Original	Rechange
MUTE	MUTE
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
-/--	Guide
AV	AV
Menu	Menu
Red	Red
OK	Ok

Original	Rechange
Green	Green
P:P	Pre Ch
Yellow	Yellow
Analog	Smart
Blue	Blue
Up	Up
P+	Ch +
P-	Ch -
Down	Down
Right	Right
Vol+	Vol +
Vol-	Vol -
Left	Left
Recall	Back
Sleep	Sleep
Status	3D
Tv/TXT	Text





Original	Recharge	Original	Recharge
 Stop	 Stop		
 Reveal	 Media		
 Size	 Format		
 Mix	 Options		
 Index	 Info		
 Subcode	 Subt		
 Cancel	 Shift + Back		

Original	Recharge

