







































































Original		Recharge		Original		Recharge	
	Power		Power		Yellow		Yellow
	TV		TV/R		Blue		Blue
	VT		Smart		Mute		Mute
	1		1		Vol+		Vol +
	2		2		Vol-		Vol -
	3		3		i		Info
	4		4		(= =)		Text
	5		5		→←		Media
	6		6		[]		Subt
	7		7		(o)		Options
	8		8		Audio		Dual
	9		9		Up Blue		Up
	0		0		Down Blue		Down
	P+		Ch +		Up Yellow		Right
	P-		Ch -		Down Yellow		Left
	Red		Red		+		Shift + Ch +
	Green		Green		-		Shift + Ch -





Original		Recharge	
	Contrast +		Shift + Up
	Contrast -		Shift + Down
	Balance +		Shift + Right
	Balance -		Shift + Left
	Men		Menu
	X		Exit
	[>=]		AV
[::] icon"/>	[:::]		Format
[00:00] icon"/>	[00:00]		3D
? icon"/>	?		Pre Ch

Original		Recharge	

