







































































Original		Recharge		Original		Recharge	
	Power		Power		Enter		Shift + OK
	Mute		Mute / Dimmer		Tv		TV/Radio /
	Right/Vol+		Right		Scart		>> / Tune+
	Left/Vol-		Left		AV		AV / Input / RDS
	1		1		PC		Fav / Marker / PC
	2		2		Sleep		Sleep / Timer
	3		3		Freeze		Pause / Step / Freeze
	4		4		Wide		Picture / Format
	5		5		Display		Display / Media
	6		6		Menu		Menu / Home
	7		7		e		Info / Angle
	8		8		MPX		Exit / Cancel / Clear
	9		9		PIP/PBP		D.Menu / Top
	0		0		Up CH		Up
	CH+		CH+ / Page+		Down CH		Down
	CH-		CH- / Page-		Vol-		Vol-
	Recall		Back / Return		Vol+		Vol+





Original		Recharge		Original		Recharge	
	OK		OK				
	Swap		Play / Slow				
	Active		Shift + TV/Radio / Program				
	Position		Sound / Title				
	Size/Mode		Setup / OPT /				
	Index		Shift + Info / Angle				
	Subtitle		Subtitle / EQ				
	Reveal		<< / Tune-				
	Teletext		Text / Goto				
	Size		Zoom / Size				
	Mix		Shift + Text /				
	Subpage		Shift + Subtitle / EQ				
	Hold		Stop / Hold				
	Red		Red / Netflix / Search				
	Green		Green / APP / Repeat				
	Yellow		Yellow / YouTube / Repeat				
	Blue		Blue / Prime Video / Random				

